


–weishaupt–

manual

Installation and operating instruction



Conformity certification

5115000002

Manufacturer: **Max Weishaupt GmbH**

Address: **Max-Weishaupt-Straße
D-88475 Schwendi**

Product: Outdoor unit

WWP L 7 AERS

The product described above conforms with
the regulations of directives:

LVD	2006 / 95 / EC
EMC	2004 / 108 / EC

This product is labelled as follows:



Schwendi, 21.05.2013

ppa.

A handwritten signature in black ink, appearing to read 'Schloen'.

Dr. Schloen

Manager Research
and Development

ppa.

A handwritten signature in black ink, appearing to read 'Denkinger'.

Denkinger

Manager Production and
Quality Management

1	User instructions	5
1.1	User guide	5
1.1.1	Symbols	5
1.1.2	Target group	5
1.2	Guarantee and Liability	6
2	Safety	7
2.1	Permissible application	7
2.2	Procedure when refrigerant leaks	7
2.3	Safety measures	7
2.3.1	Normal operation	7
2.3.2	Electrical connection	7
2.3.3	Refrigeration circuit	7
2.4	Disposal	8
3	Product description	9
3.1	Type key	9
3.2	Serial number	9
3.3	Function	10
3.4	Technical data	11
3.4.1	Approval data	11
3.4.2	Electrical data	11
3.4.3	Heat source and installation location	11
3.4.4	Ambient conditions	12
3.4.5	Emissions	12
3.4.6	Capacity	13
3.4.7	Characteristic curves - heating (to EN 14511)	14
3.4.8	Characteristic curves - cooling (to EN 14511)	16
3.4.9	Operating pressure	18
3.4.10	Contents	18
3.4.11	Dimensions	18
3.4.12	Weight	18
4	Installation	19
4.1	Installation conditions	19
4.2	Installing outdoor unit	21
4.2.1	Floor mounted installation	22
4.2.2	Installation on a flat roof (optional)	23
4.2.3	Wall-mounted installation (optional)	24
5	Installation	25
5.1	Refrigerant pipework	25
5.1.1	Installing refrigerant pipework	25
5.1.2	Connecting refrigerant pipework	27
5.1.3	Check refrigerant pipework for leaks	28
5.1.4	Evacuating refrigerant pipework	29
5.2	Filling addition refrigerant	30
5.3	Record refrigerant quantity	32
5.4	Release refrigerant	33
5.5	Condensate connection	34

5.6	Electrical installation	35
5.6.1	Wiring diagram	37
6	Commissioning	38
7	Shutdown	39
8	Servicing	40
8.1	Notes on servicing	40
8.2	Cleaning the outdoor unit	41
8.3	Replace casing	42
8.4	Repairing the refrigeration circuit	43
9	Spares	44
10	Technical documentation	50
10.1	Sensor variables	50
11	Project planning	51
11.1	Foundation plan	51
12	Notes	52
13	Key word index	54









1 User instructions

1 User instructions

This installation and operating manual forms part of the appliance and must be kept on site.

1.1 User guide

1.1.1 Symbols

 DANGER	Immediate danger with high risk. Non observance can lead to serious injury or death.
 WARNING	Danger with medium risk. Non observance can lead to environmental damage, serious injury or death.
 CAUTION	Danger with low risk. Non observance can cause damage to the equipment and injury to personnel.
	Important information
	Requires direct action
	Result after an action
	Itemisation
	Range of values

1.1.2 Target group

These installation and operating instructions are intended for the operator and qualified personnel. They should be observed by all personnel working on the unit.

Work on the unit must only be carried out by personnel who have the relevant training and instruction.

Persons with limited physical, sensory or mental capabilities may only work on the unit if they are supervised or have been trained by an authorised person.

Children must not play near or on the unit.

1 User instructions

1.2 Guarantee and Liability

Guarantee and liability claims for personal and equipment damage are excluded, if they can be attributed to one or more of the following causes:

- Non approved application,
- non-observance of the installation and operating instruction,
- operation with faulty safety equipment,
- continual operation despite a fault,
- improper installation, commissioning, operation and service,
- unauthorised modifications made to the unit,
- the installation of additional components, which have not been tested with the unit,
- repairs, which have been carried out incorrectly,
- the use of non original Weishaupt parts,
- unsuitable media,
- defects in the inlet lines,
- acts of God.

2 Safety

2 Safety

2.1 Permissible application

The outdoor unit is suitable for heating and cooling of refrigerant R410A.

The unit is only suitable for domestic application. It is not suitable for use in industrial processes.

Improper use could:

- endanger the health and safety of the user or third parties,
- cause damage to the unit or other material assets.

2.2 Procedure when refrigerant leaks

The outdoor unit is filled with refrigerant. When storing and installing the unit in a room please observe:

Leaking refrigerant collects at the base of the unit. Inhalation may cause suffocation, and even death.

Avoid open flames and spark generation.

- ▶ Use protection provided on site to isolate the outdoor unit/system from the mains supply.
- ▶ Open doors and windows.
- ▶ Leave the room.
- ▶ Warn all tenants.
- ▶ Notify refrigeration engineer.

2.3 Safety measures

Safety relevant fault conditions must be eliminated immediately.

2.3.1 Normal operation

- All labels on the unit must be kept in a legible condition,
- only operate the unit with its panels fitted,
- stipulated settings, service and inspection work should be carried out at regular intervals.

2.3.2 Electrical connection

For work carried out on live parts:

- Observe the accident prevention instructions BGV A3 and adhere to local directives,
- tools in accordance with EN 60900 should be used.

2.3.3 Refrigeration circuit

- Only a competent person in accordance with §5 ChemKlimaSchutzV (Carbon Chemical Regulation) may install, alter and service a refrigeration circuit.
- Observe BG regulation "Operating works material" (BGR 500).
- Wear safety glasses and work gloves when handling refrigerant.
- Carry out soundness test with leakage detector after each service and fault rectification.

2 Safety

2.4 Disposal

Dispose of all materials used in a safe and environmentally friendly way. Observe local regulations.

Dispose of refrigerant in the correct manner.

3 Product description

3 Product description


3.1 Type key

WWP L 7 AERS

WWP	Type: Weishaupt heat pump
L	Heat source: Air
7	Size: 7
A	Version: Outdoor installation
E	Version: Single phase
R	Version: Reversible
S	Version: Split

3.2 Serial number

The serial number on the name plate identifies the product. This is required by Weishaupt's customer service department.



① Name plate

Ser. No. _____


3 Product description

3.3 Function

The outdoor unit extracts heat from the outside air. The energy extracted is transferred to the heating circuit by a refrigerant.

An internal circuit reversal means that the unit can also be used for cooling.

Overview



- ① Fan
- ② Evaporator
- ③ TO sensor (external temperature)
- ④ Circuit board
- ⑤ TE sensor (temperature of evaporator)
- ⑥ TS sensor (suction side temperature)
- ⑦ Expansion valve
- ⑧ Liquid separator
- ⑨ 4 way change-over valve
- ⑩ Refrigerant connection 5/8"
- ⑪ Refrigerant connection 3/8"
- ⑫ Compressor
- ⑬ TD sensor (pressure side temperature)
- ⑭ Condensate outlet
- ⑮ Electrical connection

3 Product description

Fan

The fan draws ambient air through the evaporator.

Evaporator

The evaporator (heat exchanger) removes the heat energy from the intake air and transfers it to the refrigerant.

Compressor

The compressor draws the refrigerant from the evaporator at low pressure and brings it to a higher pressure and temperature level.

Condenser

The condenser (heat exchanger) is fitted in the hydraulic unit.

In the condenser, the refrigerant releases the recovered energy to the heating water.

Expansion valve

In the expansion valve, the pressure and temperature are reduced to the output level. This allows the refrigerant in the evaporator to absorb heat again.

3.4 Technical data

3.4.1 Approval data

EHPA, Germany	DE-HP-00386
EHPA, Switzerland	CH-HP-00407
Basic standards	EN 60730-1 EN 60730-2 EN 60335-1

3.4.2 Electrical data

Supply voltage / frequency	230 V / 50 Hz
Total power consumption	max 11.7 A
Power consumption standby	14 W
Heating circuit pump consumption	max 87 W
Domestic water feeder pump consumption	maximum 45 W
Type of protection	IPX4
External fusing	16 A

3.4.3 Heat source and installation location

Heat source	Air
Installation location	outdoors

3 Product description

3.4.4 Ambient conditions

Temperature in operation - heating	-20 °C ... +30 °C
Temperature in operation - cooling	0 ... +46 °C
Temperature during transport / storage	-20 °C ... +60 °C
relative humidity	max 80 %, no dew point

3.4.5 Emissions

Sound levels

Dyad noise emission values to ISO 4871

Operating condition A7/W35:	
Capacity	6.5 kW
Nominal frequency	87 Hz
Measured sound power level L_{WA} (re 1 pW)	68 dB(A) ⁽¹⁾
Uncertainty value K_{WA}	1 dB(A)
Calculated sound pressure level L_{pA} (re 20 µPa)	40 dB(A) ⁽²⁾
Uncertainty value K_{pA}	1 dB(A)

⁽¹⁾ Determined to noise level measurement standard ISO 3741.

⁽²⁾ Determined at 10 metre distance from the air outlet, when free-standing.

The measured noise levels plus uncertainty values form the upper limit value, which could occur when measuring.

3 Product description

3.4.6 Capacity

Evaporator air throughput	2820 m³/h
Recommended condenser heating water throughput	1.118 m³/h / 8.6 kPa

Capacity data - heating (EN 14511)

Heating water supply temperature	+20 ... +60 °C	
Air temperature application limit	-20 ... +30 °C	
Heating water temperature differential	A2 / W35	5 K
Nominal heat capacity	A2 / W35	3.4 kW
Coefficient of performance (COP)	A2 / W35	3.41
Heating water temperature differential	A7 / W35	5 K
Nominal heat capacity	A7 / W35	5.0 kW
Coefficient of performance (COP)	A7 / W35	4.43


Capacity data - cooling (EN 14511)

Cooling water supply temperature	+4 ... +18 °C	
Air temperature application limit	0 ... +46 °C	
Cooling - temperature differential	A35 / W7	5 K
Nominal cooling capacity	A35 / W7	5.3 kW
Efficiency ratio (EER)	A35 / W7	2.47
Cooling - temperature differential	A35 / W18	5 K
Nominal cooling capacity	A35 / W18	7.0 kW
Efficiency ratio (EER)	A35 / W18	3.4

3 Product description


3.4.7 Characteristic curves - heating (to EN 14511)

Heating capacity at 35 °C water outlet temperature



- ① Air intake temperature in °C
- ② Heating capacity in kW
- ③ Compressor frequency


Coefficient of performance (COP) at 35 °C water outlet temperature



- ① Air intake temperature in °C
- ② Coefficient of performance
- ③ Compressor frequency


3 Product description

Heating capacity at 55 °C water outlet temperature



- ① Air intake temperature in °C
- ② Heating capacity in kW
- ③ Compressor frequency

Coefficient of performance (COP) at 55 °C water outlet temperature




- ① Air intake temperature in °C
- ② Coefficient of performance
- ③ Compressor frequency

3 Product description

3.4.8 Characteristic curves - cooling (to EN 14511)

Cooling capacity at 18 °C water outlet temperature




① Air intake temperature in °C

② Cooling capacity in kW

③ Compressor frequency

Efficiency ratio (EER) at 18 °C water outlet temperature




① Air intake temperature in °C

② Coefficient of performance

③ Compressor frequency


3 Product description

Cooling capacity at 7 °C water outlet temperature



- ① Air intake temperature in °C
- ② Cooling capacity in kW
- ③ Compressor frequency

Efficiency ratio (EER) at 7 °C water outlet temperature



- ① Air intake temperature in °C
- ② Coefficient of performance
- ③ Compressor frequency

3 Product description


3.4.9 Operating pressure

Refrigerant high pressure side	max 42 bar
Refrigerant low pressure side	max 19 bar

3.4.10 Contents

Refrigerant R410A	1.365 kg
-------------------	----------

3.4.11 Dimensions



① Condensate outlet opening

3.4.12 Weight

Weight empty: ca. 51 kg

4 Installation

4 Installation

4.1 Installation conditions

Check installation location



The air flow in the intake and outlet area must not be impeded.

- ▶ In areas with heavy snow fall the unit should be installed at a higher elevation or where it is protected from snow.
- ▶ Ensure intake area is kept free from leaves.



Cooled outlet air can lead to cooling of adjacent heated rooms and to icing up of footpaths, drainpipes, etc.

- ▶ Do not direct outlet air towards walls, footpaths or drainpipes.




Cooled air collects at low level and in courtyards and is drawn in again by the heat pump.

- ▶ Do not install the unit at low level or in courtyards.

The height difference between the outdoor unit and the hydraulic unit must not exceed 10 m.

In areas with strong wind, the unit should be installed in such a way that the wind does not blow directly toward the fan.

- ▶ Check the main wind direction.



Sound can be amplified when it is reflected by walls. Installation in wall niches and in wall corners adversely affect the sound emissions.

- ▶ The unit should preferably be installed in an open area.

- ▶ Observe requirements of TA Noise relative to noise emissions (see Ch. 3.4.5). For example distance to bedrooms, terraces, etc.
- ▶ Check bearing capacity of floor (see Ch. 3.4.12).
- ▶ Ensure the floor is even and level.
- ▶ If necessary concrete foundations (see Ch. 11.1).
- ▶ If necessary check bearing capacity of masonry when wall mounting.
- ▶ Check pipework path.
- ▶ Provide frost free condensate outlet or ensure that condensate water can drain away unimpeded.
- ▶ Ensure accessibility for servicing.

4 Installation

Minimum clearances

Do not install the unit near doors and windows. Do not let the outlet air blow against windows of neighbouring buildings.




CAUTION

Problems caused by non-compliance with minimum clearances

A short circuit of the air flow can cause problems.

- Do not place solid objects near the air inlet and outlet area.

- Observe minimum clearance to buildings and sold objects:



4 Installation

4.2 Installing outdoor unit



DANGER

Risk of suffocation due to leaking refrigerant

Leaking refrigerant collects at the base of the unit.
Inhalation may cause suffocation, and even death.

Contact with the skin can cause frostbite.

- Do not damage refrigeration circuit.



WARNING

Environmental damage due to leaking refrigerant

Refrigerant contains fluorinated greenhouse gases in accordance with the Kyoto Protocol and must not be discharged into the atmosphere.

- Do not damage refrigeration circuit.



CAUTION

Damage to the unit by tilting

Compressor could be damaged.


- When transporting, do not tilt the unit more than 45°.

Observe wind load in accordance with DIN 1055 and protect depending on structural conditions on site.

Break out openings for condensate outlet

The condensate must be drained from the unit by the shortest route. This also applies when using trace heating for the condensate pan (accessory).

- Break out pre-cut openings ① in the base.
- ✓ Condensate water can also drain away through these openings.




4 Installation

4.2.1 Floor mounted installation


The outdoor unit must have a minimum clearance of 10 cm from the floor and must be installed at least 20 cm above any expected snow level.

Weishaupt recommends a strip foundation (see Ch. 11.1).


- ▶ Place unit on to the floor or foundation and align horizontally.
- ✓ Condensate can seep into the gravel.
- ▶ Specify on which side the electrical wiring and refrigerant pipework should be routed.



- ▶ Secure unit to floor using M8 screws ①.



- ▶ Break out pre-cut break point using a screwdriver.
- ▶ Deburr the opening and fit edge protection supplied.




4 Installation


4.2.2 Installation on a flat roof (optional)

Weishaupt recommends mounting rails (accessory) for installation on a flat roof.

- Fit mounting rails ① to the roof.
- Place unit on to the mounting rails and align horizontally.
- Secure unit to the mounting rails using the 4 screws ② provided.



- Specify on which side the electrical wiring and refrigerant pipework should be routed.
- Break out pre-cut break point using a screwdriver.
- Deburr the opening and fit edge protection supplied.




4 Installation


4.2.3 Wall-mounted installation (optional)

The following should be noted when mounting the wall bracket (accessory):

- ensure sufficient space is available below the unit for refrigerant pipework
- suitable fixing material should be provided according to the construction of the wall (see Ch. 3.4.12),
- condensate will only drain away, when the unit is placed horizontally.
- Install wall bracket in accordance with the installation instructions.
- Position wall bracket ② horizontally and secure to the wall.
- Place unit on to the wall bracket and align horizontally.
- Secure unit to the wall bracket using the 4 screws ① supplied.



- Specify on which side the electrical wiring and refrigerant pipework should be routed.
- Break out pre-cut break point using a screwdriver.
- Deburr the opening and fit edge protection supplied.



5 Installation

5 Installation

5.1 Refrigerant pipework

Use only 3/8" and 5/8" copper piping to EN-12735-1 suitable for refrigerant, and temperature resistant insulation up to 110 °C (accessory).



Damage caused by contaminants in the refrigerant circuit

Moisture or dirt can enter the refrigerant circuit.

- ▶ Do not use second-hand refrigerant pipework.
- ▶ Use only closed refrigerant pipework.

5.1.1 Installing refrigerant pipework



Risk of injury due to incorrectly installed pipework


Emergency exits and traffic routes must be freely accessible.

- ▶ Route pipework in such a way that it does not pose any danger to persons.

Observe the following during installation:

- An interaction with other supply pipework can occur when installing in ducts (i.e. hot flue gas pipe). If necessary insulate supply pipework
- Do not install pipework in elevator shafts
- install pipework in public stairways and passages at a height of at least 2.20 m
- when installing on fire-resistant walls and ceilings pipework should be sealed with fire-retarding material
- Protect pipework from excessive stress, e.g. distortion, do not use as brackets
- Protect pipework from environmental influences (e.g. dirt, waste, water)

Observe maximum length of refrigerant pipework:



5 Installation

- ▶ Define wall openings and breakthroughs for refrigerant pipework and electrical wiring whilst observing:
 - 3/8" refrigerant pipework external diameter 28 mm
 - 5/8" refrigerant pipework external diameter 36 mm.
- ▶ Drill wall breakthrough.



Damage caused by contaminants in the refrigerant circuit

Moisture or dirt can enter the refrigerant circuit.

- ▶ Ensure pipes are clean prior to and during installation.
- ▶ Plug pipes when installing through walls.



Damaged pipework caused by kinking

Copper pipes kink easily and can then no longer be used.

- ▶ Do not step onto the copper pipes.
- ▶ Choose sufficiently large bending radius, and/or use pipe bending device.

- ▶ Install refrigerant pipework using the most direct route with minimum bends/fittings.
- ▶ Install pipe brackets at a minimum distance of 2 m.
- ✓ Oscillations are avoided.
- ▶ Use protective tubes when installing under ground.



Damage to the building structure caused by condensate water

If the pipework is not insulated, or if the insulation is damaged, condensate water will build up.

- ▶ Fully insulate the pipework.

- ▶ Check if
 - the pipework is fully insulated
 - all joints are wrapped with insulating tape
- ▶ If necessary wrap damaged insulation with insulating tape (accessory).
- ▶ All wall breakthroughs should be sealed by others.


5 Installation

5.1.2 Connecting refrigerant pipework

- ▶ Shorten pipework using pipe cutter to required length and deburr. Ensure no splinters fall into the pipework.

Follow the guidelines for flare nut connections to EN 378-2.

- ▶ Use the pre-mounted flare nuts supplied with the hydraulic unit and outdoor unit.
- ▶ Push flare nut over the pipe end.
- ▶ Create a flare nut connection at each pipe end, making sure that:
 - the flare nut ends do not have any burrs or faults,
 - the wall length of the cup ① is equal.




Refrigerant may escape due to incorrect torque

Refrigerant may escape if the torque is insufficient. If the torque is too high, the pipework could be damaged and this would also allow refrigerant to escape.

- ▶ Torques to EN 378-2 should be used.

- ▶ Connect 3/8" pipework ① and 5/8" pipework ② to the outdoor unit and hydraulic unit, counter-holding using a second spanner.




5 Installation

5.1.3 Check refrigerant pipework for leaks



Service valves are closed at the factory. They must not be opened for leakage testing.

- ▶ Remove the cap ③ from the Schrader valve ④ of the 5/8" pipework (hot gas pipe).
- ▶ Connect manifold gauge ① to the Schrader valve ④.
- ▶ Remove the cap ② from the Schrader valve ⑤ of the 3/8" pipework (liquid pipe).
- ▶ Connect gauge ⑨ to the Schrader valve of the 3/8" pipework.
- ▶ Check for leaks with dry Nitrogen ⑩:
 - high pressure side test pressure approx. 42 bar,
 - duration of test minimum 15 minutes.
- ▶ Check connections and joints of pipework.
- ▶ If necessary, rectify any leaks.




- ① Digital manifold gauge
- ② Cap of Schrader valve of 3/8" pipework
- ③ Cap of Schrader valve of 5/8" pipework
- ④ Schrader valve of 5/8" pipework
- ⑤ Schrader valve of 3/8" pipework
- ⑥ Hydraulic unit
- ⑦ 5/8" hot gas pipe
- ⑧ 3/8" liquid pipe
- ⑨ Pressure reducer
- ⑩ Dry Nitrogen
- ⑪ Outdoor unit

5 Installation

5.1.4 Evacuating refrigerant pipework

Nitrogen must be expelled from the refrigerant pipework and the hydraulic unit with excess pressure.

- ▶ Remove the cap ③ from the Schrader valve ④ of the 5/8" pipework (hot gas pipe).
- ▶ Connect manifold gauge ① to the Schrader valve ④.
- ▶ Remove the cap ② from the Schrader valve ⑤ of the 3/8" pipework (liquid pipe).
- ▶ Connect manifold gauge ① to the Schrader valve ⑤.
- ▶ Connect vacuum pump ⑨ and vacuum gauge ⑩ to the manifold gauge.
- ▶ Evacuate pipework for approx. 30 minutes.
- ✓ Final partial pressure < 4 mbar.
- ▶ Close valves on manifold gauge ①.
- ▶ Remove manifold gauge from the Schrader valves ④ and ⑤.
- ▶ Close Schrader valves with caps.
- ▶ Remove vacuum gauge.



- ① Digital manifold gauge
- ② Cap of Schrader valve of 3/8" pipework
- ③ Cap of Schrader valve of 5/8" pipework
- ④ Schrader valve of 5/8" pipework
- ⑤ Schrader valve of 3/8" pipework
- ⑥ Hydraulic unit
- ⑦ 5/8" hot gas pipe
- ⑧ 3/8" liquid pipe
- ⑨ Vacuum pump
- ⑩ Vacuum gauge
- ⑪ Outdoor unit

5 Installation

5.2 Filling addition refrigerant

The outdoor unit is pre-filled with refrigerant, which is sufficient for 20 m of single refrigerant pipework. If 20 m are exceeded, 40 g of refrigerant must be added per additional metre of single length pipework.

Example

pre-filled refrigerant is sufficient for pipework length	20 m
actual length of refrigerant pipework	22 m
pre-filled refrigerant quantity as per name plate	1365 g
additional refrigerant required (2 m at 40 g)	80 g
Total quantity	1445 g

- Calculating refrigerant quantity required.
- If additional refrigerant is required, carry out the following tasks.

5 Installation



CAUTION

Damage to the unit caused by incorrect refrigerant

Unsuitable refrigerant causes faults and damage.

- Use only R410A refrigerant.



CAUTION


Damage to the compressor caused by excess refrigerant

Over-filling can lead to bursting and therefore cause injury.

- Adhere to exact filling quantity.

Digital scales ⑨ are required.

- Fill calculated quantity of refrigerant ⑩ via the Schrader valve of the 3/8" pipework.
- Close Schrader valves with caps ② and ③.
- Check for leaks using a leak detecting device during operation.



- ① Digital manifold gauge
- ② Cap of Schrader valve of 3/8" pipework
- ③ Cap of Schrader valve of 5/8" pipework
- ④ Schrader valve of 5/8" pipework
- ⑤ Schrader valve of 3/8" pipework
- ⑥ Hydraulic unit
- ⑦ 5/8" hot gas pipe
- ⑧ 3/8" liquid pipe
- ⑨ Digital scales
- ⑩ R410A refrigerant
- ⑪ Outdoor unit

5 Installation

5.3 Record refrigerant quantity

Additional label is supplied with the outdoor unit.

- Record refrigerant quantity ① as per name plate.
- Record top-up refrigerant quantity ② and total quantity ① and ②.
- Secure additional label to the outdoor unit, next to the name plate.

Refrigerant Label


Enthält fluorierte Treibhausgase
nach dem Kyoto-Protokoll

R410A

① = kg

② = kg

① + ② = kg



① Vorgefüllte Kältemittelmenge (kg) vom Werk, siehe Typenschild

② Zusätzliche Füllmenge (kg) nach der Installation


Achtung: Füllmengen ①, ② und ① + ② mit unauslöschbarer Tinte notieren.

B035798H01

5 Installation

5.4 Release refrigerant

- ▶ Remove cap ④ from the service valve of the 3/8" pipework.
- ▶ Fully open service valve of 3/8" pipework ①.
- ▶ Remove cap ③ from the service valve of the 5/8" pipework.
- ▶ Fully open service valve of 5/8" pipework ②.
- ✓ The inflow of refrigerant into the pipework is audible.
- ▶ Close service valves with caps ④ and ③.
- ▶ Check for leaks using a leak detecting device during operation.



5 Installation

5.5 Condensate connection

Only fit condensate outlet to the unit if the drainage is piped, otherwise let condensate drip away freely.



Damage to the building structure caused by condensate

Condensate can damage and soil building structure.

- ▶ Install condensate hose in such a way that the condensate can seep into the ground unimpeded and without freezing, and does not cause damage to the building structure.

-
- ▶ If necessary, fit condensate hose with internal Ø of 16 mm (supplied by others).
 - ✓ Condensate can drain away unimpeded.
 - ▶ Do not discharge the condensate directly into the sewer due to the risk of corrosion.

Weishaupt recommends trace heating for the condensate pan (accessory).

5 Installation

5.6 Electrical installation



Risk of electric shock

Working on the unit when voltage is applied can lead to electric shock.

- ▶ Isolate unit from mains prior to carrying out work.
- ▶ Safeguard against accidental re-start.

The electrical installation must only be carried out by qualified electricians. Observe local regulations.




Damage due to incorrect wiring

Hot compressors or pipework can damage electrical wiring.


- ▶ Secure wiring in such a way that it does not come into contact with hot components.

- ▶ Remove side panel.




5 Installation

- ▶ Run power cables through recesses.
- ▶ Connect wiring as shown in the wiring diagram.
- ▶ Secure wiring with cable ties ① to bracket.
- ▶ If mounting the external sensor outside the unit, re-connect the sensor wiring to the luster terminal.



5 Installation

5.6.1 Wiring diagram



No.	Connection	Remarks
①	Outdoor unit	Voltage supply 230 V / 50 Hz
②	Internal micro fuse	6.3 A
③	Feed from sub-distributors to the outdoor unit	FI protection switch 30 mA Cross section 2.5 mm²
④	External fusing supplied by others	16 A
⑤	Connection of outdoor unit to hydraulic unit	Cross section 1.5 mm²
⑥	Hydraulic unit	
⑦	Trace heating for condensate pan (optional)	Accessories
⑧	External sensor	

6 Commissioning

6 Commissioning

See installation and operating manual of hydraulic unit.

7 Shutdown

7 Shutdown

See installation and operating manual of hydraulic unit.

8 Servicing

8 Servicing

8.1 Notes on servicing



Risk of electric shock

Working on the unit when voltage is applied can lead to electric shock.

- ▶ Isolate hydraulic unit and outdoor unit from mains prior to carrying out work.
- ▶ Safeguard against accidental re-start.



Risk of suffocation due to leaking refrigerant

Leaking refrigerant collects at the base of the unit.

Inhalation may cause suffocation, and even death.

Contact with the skin can cause frostbite.

- ▶ Do not damage refrigeration circuit.



Danger of getting burned on hot components

Hot components can lead to burns.

- ▶ Allow components to cool.



Environmental damage due to leaking refrigerant

Refrigerant contains fluorinated greenhouse gases in accordance with the Kyoto Protocol and must not be discharged into the atmosphere.

- ▶ Do not damage refrigeration circuit.

Servicing must only be carried out by qualified personnel. The unit should be serviced annually. Depending on site conditions more frequent checks may be required.



Weishaupt recommends a service contract is entered into to ensure regular inspections.

The operator should check the unit regularly for contamination and clean if necessary.

Prior to servicing

- ▶ Inform the operator about the extent of service work to be carried out.
- ▶ Switch off installation and safeguard against accidental re-start.
- ▶ Remove front side panel (see Ch. 5.6).

Following servicing

- ▶ Carry out visual inspection:
 - check pipe connections,
 - check refrigerant pipework and insulation for visible damage,
 - complete insulation of refrigerant pipework.
- ▶ If necessary replace damaged refrigerant pipework and insulation.
- ▶ Check for leaks using a leak detecting device during operation.
- ▶ Carry out a function test.
- ▶ Refit front side panel.

8 Servicing

8.2 Cleaning the outdoor unit

Observe notes on servicing (see Ch. 8.1).




Risk of injury from sharp edges

Sharp edges on the evaporator can cause injury.

- ▶ Wear protective gloves when cleaning the evaporator.


The outdoor unit should be cleaned at least once a year, preferably at the beginning of the heating season.

- ▶ Use protection provided on site to isolate the outdoor unit/system from the mains supply.
- ▶ Do not use sharp objects when cleaning, as these could damage the refrigeration circuit.
- ▶ Clean leaves and dirt away from the evaporator ① using a broom.
- ▶ If necessary use vacuum cleaner to clean evaporator.



Check condensate outlet

- ▶ Ensure the unit is isolated from the mains.
- ✓ Fan will not start.
- ▶ Remove casing ①.
- ▶ Check condensate outlet opening ② and condensate pan.
- ▶ Remove dirt if necessary.
- ✓ Condensate can drain away unimpeded.




8 Servicing

8.3 Replace casing

Notes on servicing (see Ch. 8.1).

To replace the corner post ② and the rear side panel ③ the cover ① has to be removed.

- ▶ Remove screw and unhook the front side panel ⑥ downward.
- ▶ Remove screws and remove service covers ④ and ⑤.
- ▶ Remove screws and remove air grill ⑧, front panel ⑦ and nozzle ring ⑨.
- ▶ Remove screws and remove cover ①, whilst supporting the rear side panel ③ and corner post ②.
- ▶ Remove screws and remove side panel ③ and corner post ②.
- ▶ Refit casing in reverse order.



8 Servicing

8.4 Repairing the refrigeration circuit

Notes on servicing (see Ch. 8.1).

If it is suspected that the refrigerant has been leaking it is not possible to judge how much refrigerant remains in the refrigeration circuit. It is therefore necessary to remove all the remaining refrigerant and dispose of it. Refill with new refrigerant once the leak has been repaired.



Damage to the unit caused by incorrect refrigerant

Unsuitable refrigerant causes faults and damage.

- ▶ Use only R410A refrigerant.



Damage to the compressor caused by excess refrigerant


Over-filling can lead to bursting and therefore cause injury.

- ▶ Adhere to exact filling quantity.

-
- ▶ The quantity of refrigerant required can be found on the additional label (see Ch. 5.3).
 - ▶ Use a suction device to completely drain any refrigerant from the unit.
 - ▶ Dispose of drained refrigerant in an approved manner.
 - ▶ Check refrigerant pipework is not leaking (see Ch. 5.1.3).
 - ▶ Gradually fill liquid R410A refrigerant (see Ch. 5.2).
 - ▶ Close pipe connections.

9 Spares


9 Spares



9 Spares

Pos.	Description	Order No.
1.01	Front side panel	511 501 60 03 7
1.02	Rear side panel	511 501 60 05 7
1.03	Front service cover	511 501 60 07 7
1.04	Rear service cover	511 501 60 08 7
1.05	Handle	511 501 60 18 7
1.06	Cover	511 501 60 11 7
1.07	Corner post	511 501 60 09 7
1.08	Air grill	511 501 01 01 7
1.09	Front panel	511 501 60 01 7
1.10	Nozzle ring	511 501 60 17 7
1.11	Fan blade	511 501 60 15 7
1.12	Condensate outlet	499 059



9 Spares



9 Spares

Pos.	Description	Order No.
2.01	4 way change-over valve	511 501 60 23 7
	– coil for 4 way change-over valve	511 501 60 35 7
2.02	Service valve 5/8" complete	511 501 60 27 7
	– Flare nut connection SAE 5/8"	452 649
2.03	Service valve 3/8" complete	511 501 60 29 7
	– Flare nut connection SAE 3/8"	452 648
2.04	Attachment expansion valve PMV	511 501 60 25 7
2.05	Filter for refrigeration circuit	511 501 60 37 7
2.06	Temperature limiter	511 501 60 21 7
2.07	Bracket temperature limiter	511 501 60 22 7

9 Spares



9 Spares

Pos.	Description	Order No.
3.01	Fan motor	511 501 60 12 7
3.02	Fan nut	511 501 60 14 7
3.03	Control box (circuit board)	511 501 60 30 7
	– Base P.C. Board (circuit board)	511 501 60 50 7
	– Terminal rail 6P, 20 A	511 501 60 51 7
3.04	Inductor	511 501 60 32 7
3.05	TD sensor pressure side temperature NTC 50 kΩ	511 501 60 40 7
3.06	TE sensor evaporating temperature NTC 10 kΩ	511 501 60 41 7
3.07	TS sensor suction side temperature NTC 10 kΩ	511 501 60 42 7
3.08	TO sensor external temperature NTC 10 kΩ	511 501 60 43 7

10 Technical documentation

10 Technical documentation

10.1 Sensor variables

TE sensor evaporating temperature	TD sensor pressure side temperature
TS sensor suction side temperature	
TO sensor external temperature	
External sensor (accessory)	
Water temperature sensor	
Refrigerant pipework temperature sensor	
De-couple sensor	
Hot water sensor B3	

NTC 10 kΩ		NTC 50 kΩ	
°C	Ω	°C	Ω
-20	96807	20	72000
-15	72809	40	27000
-10	55253	60	16000
-5	42282	80	7000
0	32640		
5	25391		
10	19902		
15	15713		
20	12493		
25	10000		
30	8056		
35	6530		
40	5325		
45	4367		
50	3601		
55	2985		
60	2487		
65	2082		
70	1751		
75	1480		
80	1256		


11 Project planning

11 Project planning

11.1 Foundation plan

Overhead view


► Run changes in direction of the drainage pipe ② only with elbows $\leq 30^\circ$.



- ① Concrete base
- ② Drainage pipe \varnothing 100 mm
- ③ Gravel layer

Front view

The concrete base should be 20 cm above the maximum snow level expected, and a minimum of 10 cm from the floor.



- ① Concrete base
- ② 10 ... 20 cm above the expected snow level
- ③ Gravel layer
- ④ Soil

12 Notes

12 Notes

12 Notes

13 Key word index

A	
Accident Prevention Regulations	7
Air throughput	13
Ambient conditions	12
Approval data	11
C	
Capacity	13
Casing	42
Characteristic curve cooling	16, 17
Characteristic curve heating	14, 15
Check for leaks	28
Cleaning	41
Clearance	20
Coefficient of performance	14, 15
Components	10
Compressor	11
Condensate	21
Condensate connection	34
Condensate outlet	41
Condenser	11
Content	18
Cooling	13
COP	14, 15
Copper piping	25
D	
Dimensions	18
Disposal	8
E	
EER	16, 17
Efficiency ratio	16, 17
Electrical data	11
Electrical installation	35
Electrical wiring	36
Evacuating	29
Evaporator	11
Expansion valve	11
F	
Fabrication number	9
Fan	11
Filling refrigerant	31
Floor mounted installation	22
Foundation plan	51
Function	10
G	
Guarantee	6
I	
Installation	22
Installation location	19
Installing refrigerant pipework	25
Insulation	25, 26
L	
Liability	6
M	
Manifold gauge	29
Minimum clearance	20
N	
Name plate	9
Noise emission value	12
O	
Occupational Safety	7
Operating pressure	18
P	
Power consumption	11
R	
Refrigerant	18
Refrigerant circuit	7
Refrigerant leakage	7
Refrigerant pipework	25, 27
S	
Safety measures	7
Sensor characteristics	50
Serial number	9
Service	40
Servicing	40
Sound power level	12
Sound pressure level	12
Spare part	45
Standards	11
Sticker refrigerant	32
Storage	12
Supply voltage	11
T	
Temperature	12
Temperature differential	13
Topping up refrigerant	30
Top-up quantity	30
Transport	12
Type key	9
V	
Voltage supply	11
W	
Wall bracket	24
Wall-mounted installation	24
Weight	18
Wind direction	19
Wiring diagram	37

The complete program: Reliable technology and prompt, professional service

	<p>W Burners up to 570 kW</p> <p>The compact burners, proven millions of times over, are economical and reliable. Available as gas, oil and dual fuel burners for domestic and commercial applications.</p> <p>The purflam® burner version with special mixing head gives almost soot-free combustion of oil with greatly reduced NOx emissions.</p>	<p>Wall-hung condensing boilers for oil and gas up to 240 kW</p> <p>The wall-hung condensing boilers WTC-GW and WTC-OW have been developed to meet the highest demands in ease of operation and efficiency.</p> <p>Modulating operation means these units operate quietly and economically.</p>	
	<p>monarch® WM Burners and Industrial Burners up to 11,700 kW</p> <p>These legendary industrial burners are durable and versatile.</p> <p>Numerous variations of oil, gas and dual fuel burners meet a wide range of applications and capacity requirements.</p>	<p>Floor standing condensing boiler for oil and gas up to 1,200 kW</p> <p>The floor-standing boilers WTC-GB and WTC-OB are efficient, low in emissions and versatile. Higher capacities are achieved by cascading up to four gas-fired condensing boilers.</p>	
	<p>WK Burners up to 28,000 kW</p> <p>These industrial burners of modular construction are adaptable, robust and powerful.</p> <p>Even on the toughest industrial applications these oil, gas and dual fuel burners operate reliably.</p>	<p>Solar systems</p> <p>The stylish flat-plate collectors are the ideal complement for any Weishaupt heating system. They are suitable for solar water heating and for combined heating support.</p> <p>With versions for on-roof, in-roof and flat roof installations, solar energy can be utilised on almost any roof.</p>	
	<p>multiflam® Burners up to 17,000 kW</p> <p>This innovative Weishaupt technology for medium and large burners provides minimum emission values at capacities up to 17 MW.</p> <p>The burners with the patented mixing head are available for oil, gas and dual fuel operation.</p>	<p>Water heaters / energy storage tanks</p> <p>This attractive program for domestic water heating includes classic water heaters, solar storage tanks, heat pump storage tanks and energy storage tanks.</p>	
	<p>MCR Technology / Building Automation from Neuberger</p> <p>From control panels to complete building management systems - at Weishaupt you can find the entire spectrum of modern control technology. Future orientated, economical and flexible.</p>	<p>Heat pumps up to 130 kW</p> <p>The heat pump range offers solutions for the utilisation of heat from the air, the soil or ground water.</p> <p>Some systems are also suitable for cooling buildings.</p>	
	<p>Service</p> <p>Weishaupt customers can be assured that specialist knowledge and tools are available whenever they are needed. Our service engineers are fully qualified and have extensive product knowledge, be it for burners, heat pumps, condensing boilers or solar collectors.</p>	<p>Geothermal probe drilling</p> <p>With its daughter company, BauGrund Süd, Weishaupt also offers geothermal probe and well drilling. With the experience of more than 10,000 systems and more than 2 million meters of drilling, BauGrund Süd offers a comprehensive service program.</p>	